
Road vehicles — Fuse-links —

Part 1:

Definitions and general test requirements

Véhicules routiers — Liaisons fusibles —

Partie 1: Définitions et exigences générales d'essai

STANDARDSISO.COM : Click to view the full PDF of ISO 8820-1:2008



PDF disclaimer

This PDF file may contain embedded typefaces. In accordance with Adobe's licensing policy, this file may be printed or viewed but shall not be edited unless the typefaces which are embedded are licensed to and installed on the computer performing the editing. In downloading this file, parties accept therein the responsibility of not infringing Adobe's licensing policy. The ISO Central Secretariat accepts no liability in this area.

Adobe is a trademark of Adobe Systems Incorporated.

Details of the software products used to create this PDF file can be found in the General Info relative to the file; the PDF-creation parameters were optimized for printing. Every care has been taken to ensure that the file is suitable for use by ISO member bodies. In the unlikely event that a problem relating to it is found, please inform the Central Secretariat at the address given below.

STANDARDSISO.COM : Click to view the full PDF of ISO 8820-1:2008



COPYRIGHT PROTECTED DOCUMENT

© ISO 2008

All rights reserved. Unless otherwise specified, no part of this publication may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm, without permission in writing from either ISO at the address below or ISO's member body in the country of the requester.

ISO copyright office
Case postale 56 • CH-1211 Geneva 20
Tel. + 41 22 749 01 11
Fax + 41 22 749 09 47
E-mail copyright@iso.org
Web www.iso.org

Published in Switzerland

Contents

Page

Foreword	iv
1 Scope	1
2 Normative references	1
3 Terms and definitions	1
4 Marking, labelling and colour coding	3
5 Tests and requirements	3
5.1 General	3
5.2 Voltage drop	3
5.3 Transient current cycling	4
5.4 Environmental conditions	5
5.5 Operating time rating	8
5.6 Current steps	8
5.7 Breaking capacity	9
5.8 Strength of terminals	10
6 Dimensions	10

Foreword

ISO (the International Organization for Standardization) is a worldwide federation of national standards bodies (ISO member bodies). The work of preparing International Standards is normally carried out through ISO technical committees. Each member body interested in a subject for which a technical committee has been established has the right to be represented on that committee. International organizations, governmental and non-governmental, in liaison with ISO, also take part in the work. ISO collaborates closely with the International Electrotechnical Commission (IEC) on all matters of electrotechnical standardization.

International Standards are drafted in accordance with the rules given in the ISO/IEC Directives, Part 2.

The main task of technical committees is to prepare International Standards. Draft International Standards adopted by the technical committees are circulated to the member bodies for voting. Publication as an International Standard requires approval by at least 75 % of the member bodies casting a vote.

Attention is drawn to the possibility that some of the elements of this document may be the subject of patent rights. ISO shall not be held responsible for identifying any or all such patent rights.

ISO 8820-1 was prepared by Technical Committee ISO/TC 22, *Road vehicles*, Subcommittee SC 3, *Electrical and electronic equipment*.

This third edition cancels and replaces the second edition (ISO 8820-1:2002), which has been technically revised.

ISO 8820 consists of the following parts, under the general title *Road vehicles — Fuse-links*:

- *Part 1: Definitions and general test requirements*
- *Part 2: User's guide*
- *Part 3: Fuse-links with tabs (blade type)*
- *Part 4: Fuse-links with female contacts (type A) and bolt-in contacts (type B) and their test fixtures*
- *Part 5: Fuse-links with axial terminals (Strip fuse-links) Types SF 30 and SF 51 and test fixtures*
- *Part 6: Single-bolt fuse-links*
- *Part 7: Fuse-links with tabs (Type G) with rated voltage of 450 V*

Road vehicles — Fuse-links —

Part 1: Definitions and general test requirements

1 Scope

This part of ISO 8820 defines terms and specifies general test requirements for fuse-links for electrical systems of road vehicles.

This part of ISO 8820 is intended to be used in conjunction with other parts of ISO 8820, to which its requirements are applicable except where modified by the particular requirements of another part.

This part of ISO 8820 is not applicable to fuse holders used in the vehicles.

2 Normative references

The following referenced documents are indispensable for the application of this document. For dated references, only the edition cited applies. For undated references, the latest edition of the referenced document (including any amendments) applies.

ISO 6722, *Road vehicles — 60 V and 600 V single-core cables — Dimensions, test methods and requirements*

ISO 8820 (all parts), *Road vehicles — Fuse-links*

ISO 16750-3, *Road vehicles — Environmental conditions and testing for electrical and electronic equipment — Part 3: Mechanical loads*

ISO 16750-5, *Road vehicles — Environmental conditions and testing for electrical and electronic equipment — Part 5: Chemical loads*

IEC 60068-2-70, *Environmental testing — Part 2: Tests — Test Xb: Abrasion of marking and letterings caused by rubbing of fingers and hands*

3 Terms and definitions

For the purposes of this document, the following terms and definitions apply.

3.1

fuse

protective device that interrupts the circuit irreversibly when the current flow reaches a specified value for a specific time

NOTE The fuse is an assembly of all parts forming the protective device. This includes the fuse holder and the fuse-link.

3.1.1

fuse holder

device connecting the fuse-link to the vehicle wiring harness

3.1.2

fuse-link

interchangeable part of the fuse, consisting of an insulator and electrical conducting parts such as the terminals and the fuse element

3.1.2.1

insulator

electrical non-conductive mechanical support for the electrical conductive parts of the fuse-link

3.1.2.2

terminal

part of the fuse-link that makes the mechanical and electrical connection of the fuse-link to the fuse holder

NOTE The terminal includes contacts and tabs.

3.1.2.3

fuse-element

active part of the fuse-link which interrupts the current and opens the circuit permanently in the case of an over current

3.2

rated current

I_R

current used for identifying the fuse-link, according to specified tests

NOTE The continuous current is lower than the rated current

3.3

rated voltage

U_R

maximum supply voltage for which the fuse-link is designed

3.4

voltage drop

U_D

voltage measured between specified measuring points at a specified current

3.5

breaking capacity

I_B

value of prospective breaking current a fuse-link is capable of breaking at rated voltage under prescribed conditions of use and behaviour

3.6

time constant

time required for a physical quantity to rise from 0 to $1 - 1/e$ (i.e. 63,2 %) of its final steady value when it varies with time, t , as $1 - 1^{-kt}$

3.7

operating time

time between the application of an over current and the moment when the current drops below a value, as specified in the appropriate part of ISO 8820

4 Marking, labelling and colour coding

The rated current and rated voltage shall be permanently marked to be externally visible on the fuse-link. In addition, the current rating shall be shown by colour coding as specified in the applicable part of ISO 8820.

The manufacturer's name, trademark and/or symbol shall be marked on the fuse-link insulator.

5 Tests and requirements

5.1 General

5.1.1 General test conditions

If not otherwise specified, all tests shall be done at room temperature (RT) $(23 \pm 5) ^\circ\text{C}$, at a relative humidity (RH) of 45 % to 75 % (standard condition).

At the beginning of the electrical tests, a direct current shall be fixed at the rated value. Measure this current with an appropriate method. If not otherwise specified, no further adjustments during the tests are allowed.

All electrical measurement equipment shall have a tolerance of less than ± 2 %.

If not otherwise specified, the supply voltage shall not exceed the rated voltage of the fuse-link.

Mount the fuse-links in a test fixture as specified in the applicable part of ISO 8820, or any alternate fixture with equivalent electrical, mechanical and thermal properties.

Measurements shall be performed at no forced air flow.

For appropriate cable sizes, see the applicable part of ISO 8820.

Connections shall be made to the fuse-links with copper cables according to ISO 6722. The cable length between the test fixture and the rest of the test set-up shall be (500 ± 50) mm, if not otherwise specified.

Measure the connection resistance using a dummy with dimensions as specified in the appropriate part of ISO 8820. Use a current as specified in the appropriate part of ISO 8820 for this measurement.

5.1.2 General performance requirements

The general performance requirements are as follows:

- the marking and/or labelling shall remain legible;
- the colour coding shall remain recognisable;
- after testing, the fuse-link shall be removable in one piece from the test fixture by its intended method.

5.2 Voltage drop

5.2.1 Purpose

This test defines and measures the energy consumption of the fuse-link which creates a temperature rise.

5.2.2 Test

If not otherwise specified, this test shall be performed at rated current. Record the voltage drop measured at the points shown in the applicable part of ISO 8820, after the values are stabilized, i.e. the values do not change more than 2 % within a 10 min period.

5.2.3 Requirement

The maximum voltage drop shall not exceed the values given in the applicable part of ISO 8820.

5.3 Transient current cycling

5.3.1 Purpose


This test evaluates the ability of the fuse-link to withstand the energy volume of transient pulses.

5.3.2 Test

Apply a pulse as given in the appropriate part of ISO 8820.

5.3.3 Requirement

After transient current cycling for a minimum of 50 000 cycles, the fuse-links shall meet the requirements of the operating time rating test given in the applicable part of ISO 8820.



Key

- I current
- t time, in s
- 1 one cycle

Figure 1 — Transient current cycling

5.4 Environmental conditions

5.4.1 Purpose

These tests evaluate the ability of the fuse-links to function under environmental stresses.

5.4.2 Mechanical load

5.4.2.1 Test

If a mechanical load test is required, an appropriate test shall be chosen from ISO 16750-3 and agreed between fuse-link and vehicle manufacturer.

5.4.2.2 Requirement

After the mechanical load test, the fuse-links shall meet the requirements of the operating time rating test given in the applicable parts of ISO 8820.

5.4.3 Climatic loads

5.4.3.1 Temperature/humidity cycling


5.4.3.1.1 Test

Subject the fuse-links to a temperature/humidity cycling test as specified in Figure 2. The test sequence is as described below.

- a) Maintain the samples at standard conditions for 4 h.
- b) Increase t to $(55 \pm 2) ^\circ\text{C}$ at 95 % to 99 % RH within 0,5 h.
- c) Maintain t at $(55 \pm 2) ^\circ\text{C}$ at 95 % to 99 % RH for 10 h.
- d) Decrease t to $(-40 \pm 2) ^\circ\text{C}$ within 2,5 h; the humidity is uncontrolled.
- e) Maintain t at $(-40 \pm 2) ^\circ\text{C}$ for 2 h; the humidity is uncontrolled.
- f) Increase t to $(120 \pm 2) ^\circ\text{C}$ within 1,5 h from $(-40 \pm 2) ^\circ\text{C}$; the humidity is uncontrolled.
- g) Maintain t at $(120 \pm 2) ^\circ\text{C}$ for 2 h; the humidity is uncontrolled.
- h) Allow to return to RT within 1,5 h; the humidity is uncontrolled.

At the end of a cycle, the test may be interrupted. During the interruption, the test samples shall remain at the standard conditions. Note the interruption in the test report.

NOTE One cycle consists of 24 h.



Key

t time, in h

T temperature, in $^{\circ}\text{C}$

Y RH

a One cycle is 24 h.

b RH is between 45 % and 75 %.

c RH is between 95 % and 100 %.

Figure 2 — Temperature/humidity cycling

5.4.3.1.2 Requirement

After a minimum of 10 cycles, the fuse-links shall meet the requirements of the operating time rating test given in the applicable part of ISO 8820 and shall remain physically intact.

5.4.3.2 Resistance against temperature shock


5.4.3.2.1 Test

The fuse-links shall be subjected to 48 temperature shock cycles, as follows (see Figure 3):

- 20 min at a temperature of $(-40 \pm 2) ^\circ\text{C}$;
- 15 s maximum transition time;
- 20 min at a temperature of $(100 \pm 2) ^\circ\text{C}$;
- 15 s maximum transition time.

After completion of the test, the operating time-rating test shall be conducted in accordance with 5.5.

The cycle described in a) to d) above shall be completed in 40 min.



Key

- X time, in min
Y temperature, in $^\circ\text{C}$
1 one cycle

Figure 3 — Resistance against temperature shock

5.4.3.2.2 Requirement

After the test, the fuse-links shall remain physically intact.

5.4.4 Chemical loads

5.4.4.1 Purpose

This test evaluates the resistance to diesel fuel, "bio" diesel fuel, unleaded petrol (gasoline), brake fluid (DOT4), engine coolant water-glycol mixture 1:1, engine oil (multi-grade) and AUS32 (Urea) (see ISO 16750-5).

5.4.4.2 Test

Use a cotton cloth with a moistened area of each fluid type in succession. Wipe 5 times with a force of 5 N over the external portions of the fuse-links (see also IEC 60068-2-70).

5.4.4.3 Requirement

After the test, the marking of the fuse-links shall remain legible and colour coding shall remain recognisable.

5.5 Operating time rating

5.5.1 Purpose

This test evaluates the ability of the fuse-links to function when subjected to electrical overloads.

5.5.2 Test

Stabilize the test fixture and fuse-link at RT prior to testing. Adjust the power supply to the test current specified in the applicable parts of ISO 8820, then apply this current to the fuse-link. Repeat this procedure for each sample.

5.5.3 Requirement

The operating time of the fuse-link shall be within the limits given in the applicable parts ISO 8820. After the test, the current through the fuse-link shall not exceed the value specified in the appropriate part of ISO 8820 at the rated voltage.

5.6 Current steps

5.6.1 Purpose

This test evaluates the ability of the fuse-links' components to withstand the prolonged heating due to low level overloads.

5.6.2 Test

First apply a current equivalent in value to the rating of the fuse-link on test until it is temperature stabilized. Sequentially increase the current in steps of 2,5 % of the fuse-link current rating in intervals until it is temperature stabilized. The test ends when the fuse-element melts and the current is interrupted.

5.6.3 Requirement

After the current step test, the current through the fuse-link shall not exceed the value as specified in the appropriate part of ISO 8820 at the rated voltage. The fuse-link shall be removable from the test fixture by its intended method after returning to RT.